

Diag.	Code	ERP No.		English Description
2	25001001	301061000100	排气口垫片	Exhaust gasket
3	25001100	306140240115	机组消声器总成	Muffler assembly
3-2				Heat Shroud
5	LMB08			Flange hd hex. nut
10	LSB06012			Flange head bolt
11	TD06		弹垫06	Spring washer
12	PD06			Washer
13	25001004		消声器上支架	Muffler support A
14	LSB08020			Flange HD Hex. Bolt
15	TD08			Spring washer
16	PD08			Washer
17	25001005		消声器下支架	Muffler support B
18	LSB08020			Flange HD Hex. Bolt
19	TD08			Spring washer
20	PD08			Flat washer
21	LSB06012			Flange hd hex. bolt
22	TD08			Spring washer
23	PD08			Flat washer
26	LSB05012			Tapping screw
27	25002002	304018016000	电机风扇	Alternator fan
28	30002100	204411116001	转子总成	Rotor
		5014101020202	压敏电阻	Varistor
29	25002003		球轴承	Ball bearing
30	PDC08		大平垫8	Washer
31	TDA08		弹垫08	Spring washer
32	LZA08230	304034023000	φ 190转子中心螺栓 (8.8级)	Hex. bolt
33	30002200	204341104001	定子总成	Stator assembly
34	30002004	304030085000	定子护罩 (φ 190保护带)	Stator protector
35	25002005	304023019004	190后端盖	Rear cover
36	LSB06145		LT3000CL固定后端盖法兰螺栓	Flange hd hex. bolt
37	25002300	304027102003	AVR	AVR
37-1	25002006	304020019000	碳刷	Carbon brush
37-2	LSB05012	402050100120	法兰螺栓 M5*12	Flange hd hex. bolt
38	LSB05012	402050100120	法兰螺栓 M5*12	Flange hd hex. bolt
42	LSB05012			Flange hd hex. bolt
42-2	TD08	432050000100	弹垫05	Spring washer
45	25002400		接线柱	Terminal block
46	LSB05012		法兰螺栓 M5*12	Flange hd hex. bolt
47	25002007	304024016000	160后端罩	End cover
48	LSB05012	402050120160	法兰螺栓M5*12	Flange hd hex. bolt
49	25003100	306140120303	LT3000CL圆管机架	Frame
50	LDA06012			Pan hd screw
51	LMA08		螺母M8	Hex. nut
52	TDA08	431080000200	平垫8	Washer
53	25003200A		LT2500动力端减震垫	Shock absorber (engine)
	25003200B	211061300200	LT2500电机端减震垫	Shock absorber (alternator)
54	TDA08			Spring washer
55	LSB08045	402080450180	法兰螺栓M8*45	Flange hd hex. bolt
56	LMA08			Flange hd hex. nut
58	25004001	307030230200	油箱盖总成	Fuel tank cap
59	25004002			Seal for Cap
60	25004003	306020070300	滤网	Fuel Strainer
61	25004100	306160230145	油箱总成	Fuel tank ass'y
62	25004004	307030230300	油标	Fuel float
63	25004005	307030230301	指示器	Fuel level Indicator
63-2				Fuel indicator cover
63-3				Top gasket cover
63-4				Glass
63-5				Gasket for glass

64	LDA05010		螺钉M 5 *1 0	Countersunk hd screw
65	LSB06012		法兰螺栓	Flange hd hex. bolt
66	PDB06			Washer
67	25004006		衬套	Collar
68	25004007	306360310100	油箱减震垫	Rubber grommet
69	LMA06		螺母M6	Hex. nut
69-2				Washer
69-3				Lock washer
70	25004200	306020071100	油开关组件	Fuel shut-off
70-2				Special nut
70-3				Rubber seal with flange
71	25004008	301061100400	油管	Fuel pipe
72	25004009	301061100600	油管夹	Clip
73	411050200120		十字盘头机牙螺钉 GB818	Special screw
74	5022001402201		电源指示灯	Power indicator light
75		305215003301	波动开关（红色, 特殊）	Engine on/off switch
76		305160045301	交流电压表	Voltmeter
77		305022501601	插座	Socket
78		305022501601		Socket
79			接地总成	Ground terminal
80			接线柱（正极）	DC positive terminal
81			接线柱（负极）	DC negative terminal
82			保险丝	Fuse
83		305170530111	断路器	Circuit breaker
84			面板后罩	Rear control panel cover
85		2050101140105	面板	Control panel ass'y
86	20001001	301130100100	箱体	Crankcase
87	YF254106		油封	Oil seal
88	ZCA6205	463620560000	球轴承	Ball bearing
89	16001002	301060100200	调速摆杆	Governor arm shaft
90	16001003	301060100300	调速摆杆锁夹	Lock pin
91	16001004		垫片6	Washer
91-2		431060000101	平垫圈	O-ring
92	LSB10015	301060101001	放油螺塞	Drain plug
93	16001005	211010601200	放油螺塞垫片	Drain plug washer
94	16001100	301060110000	调速齿轮组件	Governor kit
94-2				Governor weight
94-3				Governor weight pins
94-4				Governor gear
95	16001006	301060100600	调速轴	Governor shaft
96	16001007	301060100700	调速轴卡簧	Governor shaft clip
97	16001008	301060100800	调速推盘	Governor
98	16001004	301060100900	垫片Φ6	Washer
100	16002001	301060200104	曲轴箱盖	Crankcase cover
101	YF254106	462254106300	油封25*41.25*6	Oil seal
102	ZCA6205	463620560000	深沟球轴承6205/P63	Ball bearing
103	16002002	301060210000	带刻度机油尺	Oil filler cap
104	16002003	301060200300	机油尺密封圈	Oil filler cap gasket
105	XA0814	448080014050	定位销8*14	Sleeve
106	16002004	301060200400	曲轴箱盖垫片	Case cover gasket
107	LSC080335		法兰螺栓M8*33.5	Flange hd hex. bolt
109	20003101	301130310107	LT200曲轴V7	Crankshaft
110	16003102	301060310200	正时齿轮	Timing driving gear
111	16003103	301060110000	调速齿轮	Drive gear
		30001000	2011307222042	LT200V7
112	YJA0418	454004001800	半圆键4*18	Woodruff key
113	16003200	301060320000	连杆总成	Complete connecting rod
114	20003004	301130300400	活塞	Piston
115	16003005	301060300500	活塞销	Piston pin
116	16003006	301060300600	活塞销卡簧	Piston pin clip
117	16003300	301060330000	活塞环总成	Piston ring set

119	20004100	301130410000	气缸盖组件	Cylinder head ass'y
119-2	20004101		汽缸盖	Cylinder head
119-3	16004102		进气门导管	Intake valve guide
119-4	16004103		排气门导管	Exhaust valve guide
119-5	16004104		气门导管夹	Valve guide clip
119-6	16004105		进气门座	Intake valve seat
119-7	16004106		排气门座	Exhaust valve seat
120	LZA08042	444080380120	单机双头螺柱AM8*20	Threaded stud
121	16004007	445060830120	单机双头螺柱	Threaded stud
121-2				Flange hd hex. nut
122	XA1016	448100016050	定位销10*16	Sleeve
123	16004200	301060420001	火花塞	Spark plug
124	16004001	301060400100	气缸头密封垫	Cylinder head gasket
125	16004300	301060430000	气缸盖罩总成	Head cover
126	16004002	301060400200	气缸盖罩垫片	Head cover gasket
127	16004003	301060400301	呼吸管	Breather tube
128	LSB06012	402060120160	螺栓6*12	Flange hd hex. bolt
129	16004004	301060400400	气缸头螺栓M8*60	Flange hd hex. bolt
129-2	16004004			Flange hd hex. bolt
130	16004005	301060400500	下导风罩	Wind cover
131	LSB06012			Flange hd hex. bolt
132		301061330200	火花塞扳手	Spark plug wrench
133	20005100	301130510000	凸轮轴总成	Camshaft assembly
134	20005001	301130500100	气门挺柱	Valve pole
135	16005002	301060500200	推杆	Push rod
136	16005003	301060500300	推杆导板	Push rod guide plate
137	16005201	301060520100	气门摇臂	Valve rocker
138	16005203	301060520300	摇臂轴螺栓	Pivot nut
139	16005202	301060520200	摇臂轴座销	Rocker pivot pin
140				Special Hex. nut
141	16005004	301060500400	进气阀	Intake valve
142	16005005	301060500500	排气阀	Exhaust valve
143	16005006	301060500600	气门弹簧	Valve spring
144	16005007	301060500700	进气门弹簧座	Intake valve spring seat
145	16005008	301060500800	排气门弹簧座	Exhaust valve spring seat
146	16005009	301060500900	排气门调节帽	Valve rotator
149	16006100	301060611143	导风罩	Fan hood
150	LSB06012	402060120160	法兰螺栓	Flange head hex. bolt
151	16006201		手拉盘外壳组件	Casing
	16006200	301060623141	手拉盘总成	Recoil Ass'y
152	16006202	3,01061E+11	蜗卷盘簧	Spiral spring
153	16006203	3,01061E+11	起动拉盘	Rope reel
154	16006204	301060620006	棘爪弹簧	Ratchet spring
155	16006205	3,01061E+11	起动棘爪	Ratchet
156	16006206	301060620007	摩擦弹簧	Friction spring
157	16006207	3,01061E+11	棘爪压板	Spring lid
158	16006208	3,01061E+11	压板轴位螺钉	Flanged retainer bolt
159	16006209	301060620001	拉绳	Starter rope
160	16006210	301060620003	拉手	Pull handle
161	LSB06008	404060080120	小头法兰螺栓M6*8	Flange head hex. bolt
162	16006001	3,01061E+11	风扇后侧罩	Starter Shroud
163	LSB06012		法兰螺栓	Flange head hex bolt
164	16007001	211010607100	空滤器垫片	Air cleaner gasket
165	16007002	301060700200	化油器垫片	Carburetor gasket
166	16007003	301060700300	机组化油器接块	Connecting block
167	16007004	301060700400	进气口垫片	Inlet gasket
168	20007200A	301130710002	化油器总成	Carburetor assembly
168-2				Float chamber drain screw
168-3	16007102		浮子室放油螺钉垫片	Fiber washer
168-4	16007103		浮子室	Float chamber
168-5	16007104	301060710701	浮子室密封垫	Float chamber gasket
168-6	16007105	300301060701	浮子组合	Float

168-7				Choke butterfly
168-8		301060710201		Idle adjustment screw
168-9				Mixture adjustment screw
169-2				Spring for mixture adjustmen
169-3				Throttle unit
169-6			化油器阻风门手柄	Choke switch
170	16008200	301060820001	空滤总成	Air filter assembly
170-2				Air filter housing
170-3				Filter element housing
170-4				Air filter cover
170-5				Flange hd hex. bolt
170-6				Air filter clamps
170-7				Air filter housing seal
171	16008107	301060820101	空滤器滤芯	Air filter element
		301060820102	空滤器后盖(机组)	Air Filter cover
173	16009200	301060920004	机组调速控制组件	Speed control assembly
173-2				Speed support assembly
173-3				Pan head screw
173-4				Control adjust spring
173-5				Control pull spring
174	LSB06012			Flange hd hex. bolt
175	16009001	301060900100	调速拉杆	Governor rod
176	16009002	3,01061E+11	节气门复位弹簧	Throttle return spring
177	16009003	301060900302	调速弹簧	Governor spring
178	16009004	301060900400	调速臂	Regulating arm
179	16009005	301060900500	调速臂螺栓M6*21	Governor arm bolt
180	LMB06			Flange bolt
187	16012100	301061210001	飞轮组件	Fly wheel
188	16012001	3,01061E+11	冷却风叶	Cooling fan
189	16012002	301061200200	起动机	Starter pulley
190	16012003	301061200300	飞轮螺母M14X1.5	Fly wheel nut
191	16012004	301061200401	一体化点火线圈	Ignition coil
192	LSB06028			Flange hd hex. bolt
193	16012005	301061200502	机油油位传感器组件	Oil sensor
194	LSB06014		法兰螺栓M6*14	Flange hd hex. bolt
195	LMB10			Special nut
197	KBPC2506	5013250620001	整流桥	Diode Bridge





